



INLET VALVES 95L ASSEMBLY INSTRUCTIONS

SIAMP




2. To switch for 3/8" version. To switch for 3/8" version, please follow the below steps.






3. Inlet installation (3/8" or 1/2" brass)



INLET VALVES 95L

4. Water level adjustement



5. Maintenance



WARNINGS:

- An approved single check valve or some other no less effective backflow prevention device shall be fitted at the point of connection(s) between the supply and the fitting.
- Do not over tight in any case.
- Do not use any sealing paste and/or compound in any case

SIAMP UK will be not responsible in case these warnings are not respected.

SIAMP

Siamp Ltd / Unit C2 / Meadowbank Business Park Tweedale Way / Hollinwood / Oldham / Greater Manchester / OL9 8EH Telephone : 0161 681 2120 / Fax : 0161 681 2130 / aftersales@siamp.co.uk